OPERATOR SAFETY WARNING




Operator must have instructions before operating the machine. Untrained operators can cause injury or death.

W-2001-0502




Safety Alert Symbol:

This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.



Never operate without instructions.


Read machine signs, and **Operation & Maintenance** Manual, and Operator's Handbook.



control Do not grasp handles when entering cab / canopy.

Be sure controls are in neutral before starting.


Sound horn and check behind machine before starting.




Never operate without approved cab / canopy.

Never modify equipment.

Never use attachments not approved by Bobcat Company.




Avoid steep areas or banks that could break away.



Use caution to avoid tipping - do not swing heavy load over side of track.


A Operate on flat, level ground.




A Keep bystanders out of maximum reach area.

A Do not travel or turn with bucket extended.


A Never carry riders.




Never exceed a 15° slope to the side.



Never travel up a slope that exceeds 15°.



Never exceed 25° when going down or backing up a slope.




To leave excavator, lower the work equipment and the blade to the ground. Stop the engine.

CORRECT B-21928

Fasten seat belt securely.

Operate controls only from operator's seat.



Look in the direction of rotation and make sure no bystanders are in the work area.

SAFETY EQUIPMENT

The excavator must be equipped with safety items necessary for each job. Ask your dealer about attachments and accessories.

SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.

OPERATOR'S HANDBOOK: Must be in the cab / canopy.

3

LEFT HAND CONSOLE: When raised must deactivate the travel and hydraulic functions.

SAFETY SIGNS (DECALS): Replace if damaged. GRAB HANDLES: Replace if damaged.

INTEGRATED SLEW LOCK BRAKE. 7.

SAFETY TREAD.: Replace if damaged.